



Before commencing with applying the InnoCoat finish coat check to ensure that the surface is clean and free of dust, oil and other contaminants.
If a wash is required use a mild biodegradable detergent and allow the surface to completely dry.

Application (3) coat system

DO NOT APPLY THE InnoCoat if rain is imminent.

If there is night moisture present, leave at least 3 hours for drying time to ensure that the surface is dry enough, and can withstand any pooling of water for lengthy periods.

Tools

- 270mm wide Polypropylene paint tray.
- Lambswool flat applicator.
- 80mm wide long hair brush.
- Paint stirrer.

First Coat

Apply the first coat of the InnoCoat Natural Clear using a flat lambswool applicator or airless spray gun. Wait a minimum of 2 hours at 25CC before applying the second coat.
Coat no more than 3 to 4 boards at a time to ensure that you maintain a constant wet edge.
Apply sufficient product to completely cover the surface and constantly re load the applicator to ensure that film build is not too thin. Do not allow the product to pool and remove immediately if this happens.
Once the product has been applied do not continue to go over as this could cause the applicator to drag over the drying coating.

2) Second Coat

After the appropriate drying time for the first coat apply the second coat as per the first coat application process in the same direction. The spread rate will increase and care should be taken to ensure that sufficient product is always on the applicator.

(3) Third coat

After the appropriate dry time of the second coat, apply the third coat in the same direction as the previous coats.



Tropical & High UV exposure

In some tropical areas and on high UV exposed areas there may be a need to apply a (4) Fourth coat to maximize the protection of the colouring to reduce any fade. Remember that 1 does not fit all and careful planning should be undertaken to ensure the best protection for the coated Composite wood.

A minimum of 2 coats should always be applied as 1 coat is too thin to form any lasting protection of the Composite wood.

Clean Up

Wash all items in cold water.

Hints

Leave the InnoCoat in the paint tray with the applicator and brush, and cover over with a damp heavy cloth such as an old towel between coats. Do not leave the paint tray in direct light.

Water Damage

In the event that there is water damage through rain or night moisture, carefully remove as much of the water as is possible using a dry cloth such as a towel or use an air blower to remove the water. If there is damage to the coating such as leaving a white film on the surface then a light sand of the last coating will be required with fine sand paper and then a recoat should be applied to the affected area.

If the coating has been compromised and has crystallized then that part of the coating should be carefully sanded back to the substrate and re coated again applying the same number of affected coats.

Slip Resistant

For surfaces that require a slip resistant coating refer to the data sheet for **Slip Resistant Application Method**.